


Commander / PC Admiral
Electronic Bingo Systems

Operator's Manual

Arrow International
Equipment Division



Thank you for choosing to purchase Arrow International's Capitol Bingo Equipment. We are confident that you will be completely satisfied with our high quality, durable bingo equipment. Our Capitol Bingo Equipment has the most technologically-advanced electronics and is designed for easy and reliable operation and trouble-free maintenance by the operator.

We are proud to announce that we have been given design and safety certification approval on all our bingo equipment from Underwriter's Laboratories, Inc. (UL). Arrow International, Inc. is the only bingo equipment manufacturer that has earned the UL approval certification. Look for the UL seal of approval on all our Capitol Bingo Equipment.


Arrow manufactures the highest furniture quality, hand crafted equipment consoles in the industry. Our metal fabricated steel consoles are constructed of the finest, heavy duty materials available and guaranteed to withstand many years of use.

This equipment manual introduces you to the Commander and PC Admiral electronic bingo systems. It will take you step by step through unpacking your flashboard and the simple procedures for installation, set up and operation. Easy to follow instructions and illustrations allow you to perform routine service and maintenance.

Arrow's hard work and dedication enable us to offer you a breadth of product line that continues to grow. We are proud to offer you the most extensive charitable fundraising product line consisting of high quality, easy to open Popp-Opens™ tabs; "Top Shelf" banded jar tickets; the largest series of bingo paper available in the largest variety of colors, patterns and cuts to meet your game's needs; Tear Opens™; and our popular Wink® Ink, Ink-A-Dot™ and Electra Dot™ bingo markers. This dedication to providing an extensive line of high quality products is accompanied by our commitment to satisfying your product needs with fast and trouble free service.

We value you as a customer and always welcome and appreciate your comments and suggestions to help improve our products. Our best suggestions always come from our game operators and distributors. We want you to always be a satisfied customer, and we will continue to design and improve our products through the valuable feedback received from you and our reliable network of Arrow Distributors.

Once again, thank you for choosing Arrow International/Capitol for your charitable fundraising needs.



John E. Gallagher, Sr.
President



REVISION 4-2-92

Table of Contents

I.	Unpacking	4
	A. Console	4
	B. Flashboard	4
	Warranty Assurance	5
II.	Computer Installation	6
	A. Computer Cabling Set Up	6
III.	Flashboard Installation	7
	A. Suggested Number of Flashboard Mount Assemblies	7
	B. Wall Mounting Preparation for Flashboards	7
	C. Wall Mounting Instructions	8
	D. Ceiling Mounted Flashboards (optional)	9
	Ball Quality Assurance	11
IV.	Console Controls	11
	A. Commander and PC Admiral console blower controls	11
	B. Other Controls	11
	C. Ball Tray Select Switch—PC Admiral only	11
V.	Operation	12
VI.	Periodic Customer Servicing	14
	A. Cleaning your Bingo System	14
	B. Changing Console Light Bulbs	15
	C. Changing Flashboard Light Bulbs	16
	D. Changing Flashboard Fuses	17
VII.	Troubleshooting	18
VIII.	Electrical Specifications	25
	A. Commander console	25
	Blower Fuse	25
	B. PC Admiral console	25
	Blower Fuse	25
	C. 4" Flashboard - Numbers, Game Indicator and DV	25
IX.	Wiring Diagrams	26
	A. Commander Wiring Diagram	26
	B. PC Admiral Wiring Diagram	26
	D. 4" Flashboard Primary Wiring Schematics - Numbers, Game indicator & Dollar Value	27
	E. Bridge Rectifier	28
	F. ACRC Darlington Map	29
	G. ACRC Darlington Map Detail	29
	Capitol Bingo Equipment Limited Warranty	31

Damage Action Process

Your Capitol Bingo Equipment contains delicate electronic equipment. It is imperative that you thoroughly inspect the contents of the package before accepting from the carrier. In case of damage, make a note on the bill of lading before accepting, take a photo of the damage, and keep the packaging to aid in recovering the amount of claim against the carrier.

In case of severe damage, refuse the equipment from the carrier.

If the product is damaged but acceptable, take a photo before and after unpacking as a record of the damage and contact the carrier's agent immediately for inspection. Be sure to obtain a copy of the inspection report for your records.


If these precautions are not taken, we cannot assist you in recovering the amount of the claim against the carrier.

I. Unpacking


COMPUTER UNPACKING

MONITOR UNPACKING

SAMSON BALLS



Note: If severe damage to the carton or flashboard is discovered, a photograph will provide an excellent record and may assist in processing claims against the carrier.



A. Console

The Commander and PC Admiral are shipped via common carrier. Each system is wrapped in sheet plastic. Cut the wrapping and discard. Inspect your console for any signs of shipping damage. Immediately report any defects or shipping damage to your equipment distributor.


The computer components and optional video and sound equipment are shipped separately. Before opening any of these packages, inspect each for external damage. Again, report any visible damage to your equipment distributor.

Open the box holding the computer. Remove the top packing insert and keyboard from the box. Next, grasp the computer cabinet firmly under both ends, lift straight up and place on a secure table. Save the cartons and packing in case you need to move or ship the computer at a later time. The power cord will be on the bottom of the computer. Carefully remove all staples on the box holding the monitor. Slide the monitor out from the box. The power cord will be in the back. The DOS manuals and disk set can be found on top of the computer.

<u>Parts Included</u>	<u>Commander</u>	<u>Admiral</u>
Computer	1	1
Keyboard	1	1
Monitor	1	1
Samson Balls	1	2
Computer manual	1	1
w/ disk set	1	1
Bingo Programming Manual	1	1


B. Flashboard

Your fhboard is banded into a heavy cardboard enclosure with foam inserts at each end and in the middle. This carton is marked with various warning labels and stampings. Lay the carton down flat, observing labels indicating which side is up.



Before opening, closely inspect the carton for evidence of shipping damage such as puncture holes, tears, and crushed edges or corners. Damage on the carton may alert you to damage to the flashboard.

Use scissors to cut all straps. Carefully lift off the carton top. Slide the end pieces off to allow access to the handles. Make sure the back of the unit is facing down on the cardboard to prevent scratching. Obtain assistance in setting the flashboard upright.



Caution: This flashboard weighs approximately 185 pounds, get assistance before lifting.

Do not destroy or discard carton materials until after final inspection and testing. Inspect the flashboard to insure that all plexiglass is in place and free of cracks or heavy scratches. Inspect the masonite panels for damage. If damage to your equipment is evident, or if you have problems in any of the above areas, contact your area distributor immediately for assistance.

Warranty Assurance


At this time, please verify the serial numbers and fill out the warranty cards. On the flashboard, the serial numbers are located on the left side below the handle. On the Commander and PC Admiral console, they are located on the operator's left side near the flashboard connectors.

A second warranty card appears on the back cover of this manual. We suggest that you fill out this card and keep the information on hand for future reference.

To validate your warranty, complete all requested information and return the completed card to Arrow International.

II. Computer Installation


FLASHBOARD DATA CONNECTIONS




1. Place the computer on the top slide out drawer in the right compartment of the console. Place the printer underneath the computer on the slide out drawer in the right compartment of the console.
2. Place the monitor near the 1" hole on the top right side of the console. If you have a Commander, place the keyboard on the slide out drawer on the inside right of the console.

A. Computer Cabling Set Up

1. The ribbon cable with the large D-shaped connector (DB-25) plugs into the back of the computer labeled "Switch Bar."
2. The coiled cable with cylindrical connector plugs into the back of the computer labeled "Keyboard." Keep the notch on the plug facing up.
3. The telephone cable (RJ-12 connector) labeled "Std" plugs into the upper telephone jack on the back of the computer labeled the same.
4. The telephone cable labeled "Tear" plugs into the lower telephone jack on the back of the computer labeled as such.
5. The power cord plugs in on the bottom left side in the back of the computer, then into the outlet strip to the left of the drawer.
6. If printer is used, plug it into the large D-shaped connector in the back of the computer labeled "Par" and tighten the two knurl nuts to secure.
7. Connect the small male D-shaped 9 pin monitor connector into the matching female connector in the back right corner of the computer and tighten the two screws.
8. Connect the coax cable from the camera (if used) with the RCA plug into the top RCA on the back of the computer labeled "Video In."



PRINTER CABLE



9. Connect the coax cable with the RCA plug into the bottom RCA in the back of the computer labeled "Video Out." (the coax cable will connect with the RCA plug in the middle when installing a PC Admiral system.
10. If using a PC Admiral, connect the RCA plug labeled speaker into the bottom plug on the back of the computer.

Caution: Do not mount the flashboard from the handles. They are intended for handling only.

III. Flashboard Installation

A. Suggested Number of Flashboard Mount Assemblies

SUGGESTED NO. OF FLASHBOARD WALL MOUNT ASSEMBLIES				
	PART NO.	NUMBERS ONLY	NO. & GAME INDICATOR	NO., GAME INDICATOR & DOLLAR VALUE
2" Wall Mount	45253	2	2	3
J Bracket	415805	2	2	3
Eye Bolt	46515	2	2	3
4" Wall Mount	45254	3	3	4
J Bracket	415805	3	3	4
Eye Bolt	46515	3	3	4
8" Wall Mount	45256	3	4	4
Eye Bolt	46515	5	5	6
12" Eye bolt	46515	7	7	8

B. Wall Mounting Preparation for Flashboards

Before attempting to mount any flashboard to the wall, you must first determine the type of wall construction. For hollow walls, we recommend that the flashboard mounting brackets be fastened directly into wall studs. For concrete, brick and cinder block construction, the mounting brackets should be fastened using a bolt and anchor method (moly bolt). If other methods of wall construction are used, consider ceiling mounting or consult our service department for advice.

Your PC Admiral or Commander comes standard with a 4" dollar value brass anodized extruded flashboard.

1. 4" brass and fabricated style flashboards


Use tubular brackets mounted to either a hollow wall or masonry (solid concrete or cinder block construction) wall, or ceiling mount it. Eyebolts are available upon request.

Other options:


2. 2" brass style flashboards

Use J-brackets or tubular brackets mounted to either hollow wall or masonry (solid concrete or cinder block construction)

Caution: Before attempting any installation, have a qualified, licensed and bonded rigger or electrician verify the type of installation. Mounting the 8" and 12" jumbo flashboards requires trained personnel. In many cases, the local building inspector may require a permit as well as an inspection of the site for structural stability.



WALL MOUNT
J BRACKET



WALL
MOUNT
TUBULAR
BRACKET

wall, or ceiling mount it.

3. 8" brass style flashboards

Use ceiling mount or tubular bracket fastened to masonry wall. (Cannot be fastened to hollow wall.)

4. 12" brass style flashboards

Use ceiling mount only.

C. Wall Mounting Instructions

For hollow wall construction, use 3/8" x 3-1/2" lag bolts. Fasten brackets directly into wall studs. For masonry construction, use 3/8" x 1-1/2" or larger lag screw expansion shield with suitable length lag screw.

1. Wall Mount J bracket

(2" aluminum extruded flashboard)

Supplied with the flashboard are four J shaped wall brackets. Each bracket has four holes for 3/8" bolts. Choose the height you feel is desirable for easy viewing and mark the location on the wall. Then measure in 8-1/2" and 9-7/8" from each end of the flashboard and mark the vertical center lines. Next, from the top of the flashboard, measure up 2" and 3-3/8" from the horizontal center lines.

Before drilling any holes, check for possible items behind holes and make sure that it's level from side to side. Next, space any additional brackets equally between the previous brackets and locate mounting holes, again checking for level. Drill the proper clearance holes for the method of mounting appropriate for your wall as described above.

2. Wall Mount Tubular bracket (optional)

(2" and 4" aluminum extruded flashboard and fabricated flashboard with tubular mounting brackets)

Choose the proper height for easy viewing and mark the location on the wall. This mounting bracket supports the flashboard from the bottom and may be used to mark the mounting holes. Make sure the brackets are level and away from any obstructions. Equally space the brackets insuring that all supporting surfaces are level. Drill the proper clearance holes for the mounting method appropriate for your wall as described above.

3. Wall mounting brackets for 8" style flashboards (optional)

The 8" style flashboards can be mounted to a wall only if the wall is constructed of brick or cinder block. These flashboards are too heavy to be mounted on a wood partitioned wall. In this case, the flashboard must be hung from the ceiling with eyebolts.

Use 3/8" or larger lag screw expansion shields with a suitable length lag screw. Use two 8" wall brackets for each flashboard section. Center the wall brackets evenly to insure even distribution of weight.

D. Ceiling Mounted Flashboards (optional)

In any ceiling application, the chain or cable must be attached to the steel building frame or girder. In addition, check with the local building inspector for local codes governing weight restrictions and mounting methods.


There are two different methods for suspending these flashboards from the ceiling.

1. Chain


Use a high quality 3/8" larger chain link made of high strength alloy, steel grade 80 or its equivalent. Bolt chain together with a 3/8" x 1-3/4" bolt with two flatwashers, a lockwasher and a hex nut.

2. Cable

Use a high quality 1/8" or larger diameter high strength steel aircraft cable or its equivalent with appropriate cable clamp.



FLASHBOARDS	EYEBOLT LOCATIONS--MEASURED FROM LEFT END							
	* Measured from the left side of the second half of the flashboard							
12" Dollar Value	34 3/4"	64 1/2"	94 1/4"	124 1/2"	*22 3/8"	*67 "	*109 1/2"	*143 1/8"
12" Game Indicator	34 3/4"	64 1/2"	94 1/4"	124 1/2"	*22 3/8"	*67 "	*96 3/4"	
12" Numbers Only	21"	65 5/8"	110 1/4"	*22 3/8"	*67 "	*96 3/4"		
8" Dollar Value	21 3/4"	47 1/2"	86 5/8"	*9 5/8"	*48 3/4"	*97 3/4"		
8" Game Indicator	21 3/4"	47 1/2"	86 5/8"	*9 5/8"	*68 1/4"			
8" Numbers Only	23 5/8"	43 1/8"	82 1/4"	*9 5/8"	*68 1/4"			
4" Dollar Value	22"	46"	94"	118"				
4" Game Indicator	22"	38 3/4"	55 1/2"	72 1/4"				
4" Numbers Only	17"	49"	76"					
2" Dollar Value	18"	36"	48"					
2" Game Indicator	18"	47"						
2" Numbers Only	12"	44"						



FLASHBOARD STAND

E. Flashboard Stand (optional)


A flashboard stand allows for easy mobility and storage of your flashboard. These stands fit 2" and 4" flashboards and may be ordered through your distributor.

F. Input/Output Panel Connections


1. The input/output panel is located in the left hand compartment against the left side. Feed all flashboard cables up through the oval hole in front of the panel.
2. There are three female panel connectors for regular game flashboards; two are three pin jones and one is a RJ-12. Plug into appropriate socket; use adapter cable if necessary. The sockets are on top and are labeled "BINGO."
3. There are three outlets for the tear-open flashboards in the lower row labeled "TEAR OPEN." Two of the three outlets are three pin jones and one is a RJ-12. Insert into the appropriate socket using adapter cable if necessary.
4. Connect the coax cable with the RCA plug into the bottom RCA connector in the back of the computer labeled "Video Out."
5. If using hall monitors, connect them by running the coax cable feed with BNC plugs through the oval hole by the input/output panel. Connect to the BNC jack labeled "Video Out."

For more information on video system configuration see application note #1. (Included with camera and monitors or request from service dept.)

COMMANDER I/O PANEL



PC ADMIRAL I/O PANEL



Ball Quality Assurance

Open the box of Samson balls. Check each ball for damage and insert each into its corresponding slot in the console ball tray. If you find a ball with a flat spot, immerse it in hot water. Usually, the flat area will pop out. If the ball is damaged, contact your Arrow distributor for a replacement.

IV. Console Controls

A. Commander and PC Admiral console blower controls

1. Mixer: On/Off control for the ball mixing arm.
2. Blower: On/Off control for the ball blower motor.
3. Blower lamp: On/Off control for the blower chamber lamp.

Note: There are two (2) sets of console blower controls for the PC Admiral.

B. Other Controls

1. Audio—Controls auxiliary system power in the Commander console only.
2. Power—Controls power to the computer system in the PC Admiral.


C. Ball Tray Select Switch—PC Admiral only

1. This switch only appears on the PC admiral


Note: Please note that the flashboards function only when running a session and you may get a few random lights on the flashboards until you start a session.

Note: The PC Admiral has two ball trays; the left one can be used for Tear-Open and the right one for regular games. The Commander has one ball tray so Tear-Opens can be run with the random number generator if desired.

COMMANDER CONTROL PANEL



PC ADMIRAL CONTROL PANEL




and is used to select the left or right ball


tray.

V. Operation


INITIAL PLAY SCREEN



STANDARD SCREEN



FLASHBOARD SCREEN



If you have a PC Admiral, turn the top panel power switch to "ON". If you have a Commander, turn the "COMPUTER" switch to "ON." Initially, when you turn on the computer, it will count through its memory to 512K, display the NCR DOS version, and then ask for the date and time. Following this, the bingo program will automatically begin.

On the initial installation, run the <F7> option—"SET UP BINGO SYSTEM." This will allow you to customize your system to your hall requirements. Items such as the printer, flashboard type, and verification on last ball may be selected with this option. Please refer to the enclosed BINGO PROGRAM USER'S MANUAL for more information. Please note that the information entered during setup will be permanently saved so this option need only be used to install the system or to modify the configuration if any system parameters change (for example, new type of flashboard, etc.)

Refer to the THE BINGO PROGRAM USER'S MANUAL for instructions on programming the system. Once programmed, the sessions, messages and patterns are stored permanently on the hard disk. A bingo session is started from the main menu. Choose <F1> to bring up the session menu. After entering the session name, the screen will display the dollar amount of the first game, the present game number being played out of the total number of games in the session, the game pattern, the format, game size, game name and the six following functions:

- <F1> **Game Pacer**—Select this to change the ball timer. The timer defaults to 30 seconds.
- <F2> **Begin Game**—Select this for the standard screen to begin the bingo game.
- <F4> **Enter Wild Numbers**—Select this to enter wild numbers for the present game.
- <F5> **Immediate Message**—Select this to display messages not in the session program.
- <F9> **New Game**—Select this to increment to the next game in the session sequence.
- <F10> **Cancel Session**—Select this to cancel the session.

There are three game displays to use when running a game. There are the standard, ball list and flashboard displays. Once again, refer to THE BINGO PROGRAM USER'S MANUAL for further details.

At either the standard or ball list screen, press <F4> to display the flashboard screen. A display of the grid of the bingo board, the last ball called, the dollar amount of the current game, and the winning patterns of the current game will appear.

The following functions can also be displayed:

- <F1> **Call Ball**—When in random mode, the computer will generate the numbers at random. One number will be generated each time <F1> is pressed.
- <F2> **Standard Screen**—Will display the large last ball called display screen.
- <F5> **Save Tear**—Will save the current game and take you to the new game screen.
- <F6> **Securifier**—Allows you to interrupt a game to check for a valid bingo, delete a game pattern or change the dollar amount.
- <F10> **New Game**—Allows you to end the current game. It will then take you to the new game screen where you can end session or start next game.

Once at the flashboard screen, turn on the rocker switches for the mixer and blower motors. Proceed with your game in the normal fashion by calling a ball using the automatic timer. If you are running a tear-open game, call your first standard round of balls then depress <F5> Save Tear, switch to the right tray if using a PC Admiral and start the first regular game.


Press <F6> to get the securifier screen and the following menu is given:

- <F1> **View Face**—Enter the free space number to verify a bingo called.
- <F2> **Delete Current Pattern**—Drop the winning pattern from the list of winning patterns.
- <F7> **Change Dollar Amount**—Change the winning dollar amount such as in progressive games.
- <F10> **Return**—Return to the flashboard screen.


To verify a bingo called, press <F1>, type the face number and press "Enter." The computer will switch the hall monitors from the ball called mode to display the bingo face (computer screen will also show the bingo face). The numbers that show up in reverse video are the numbers of the balls that have been called. If there is a number flashing, it corresponds to the last ball called. In the lower right hand corner, a message will state "A Winner," "Not a Winner" or "No Last Ball." Press <F10> to return to the screen you were previously at before changing to the verify mode.

If you had a valid bingo, but are not running a progressive game, depress <F10> again to return to the flashboard screen. Then hit <F10> again to progress to the next game. If you had a valid bingo and are running a progressive game, change the dollar amount if necessary by hitting <F7> and entering the new amount. Then hit <F3> to progress to the next

VERIFY MENU



CARD FACE SCREEN



pattern.

The screen will now display the name of the next pattern. Press <F10> to continue the game. If there was not a valid bingo, hit <F10> to get back to the flashboard screen and to continue the game.

Continue this procedure until the end of the session. Pressing <F10> at the flashboard screen will take you to the main menu. To resume the Tear-Open game between games, when at the new game screen, hit <F3> to resume Tear-Open. If you are using a PC Admiral, flip the tray switch to the left and continue playing.

VI. Periodic Customer Servicing

A. Cleaning your Bingo System

Periodic servicing of your Commander and PC Admiral bingo systems should include cleaning, polishing and light bulb replacement.

Wood Consoles

Use any high quality wood and furniture polish. Apply with a soft cloth.

Painted Surfaces—Console and Flashboard

Use a mild soap solution or cleanser. Harsh cleansers or solvents may damage the paint or lettering. Follow with an automotive style polish.

Glass Surfaces—Console and Flashboard

Use mild soap solution with a clean, soft cloth.

Caution: Unplug unit before cleaning or servicing.

Caution: Overspraying may remove polish from nearby painted or wood surfaces. The front of the glass is a painted surface.

Bingo Balls

Clean with a mild soap solution such as liquid detergent. Harsh cleansers or solvents may damage paint or lettering. Dry balls thoroughly.

Insert towel dried balls into a paper bag with talcum powder. Agitate ball and shake off excess powder.

Static Treatment


Lightly spray anti-static compound over the foam and inside the ball blower windows to eliminate static. Perform this treatment every few months or when the balls begin to stick together or to the windows. Do not get anti-static compound

on the ball tube.

B. Changing Console Light Bulbs

Blower/Mixer Lamp

1. Open the blower chamber access door in the center of the console and slide out the blower tray for easy access to the lamp.
2. Remove the plexiglass lamp panel covering the bulb by turning the two plastic tabs.
3. Turn the bulb counterclockwise to remove it.
4. Insert the new bulb and turn clockwise until snug. Do not over tighten.
5. Replace the plexiglass cover and resume operation.




C. Changing Flashboard Light Bulbs

1. Remove the plastic retaining divider between the plexiglass panels. Once the strip is removed, carefully slide the panel behind the panel next to it.
2. Change the bulb.
3. Carefully slide the plexiglass panel back to its original position.
4. Re-insert the plastic divider.

To change bulbs:




1. Lightly push the bulb while turning counterclockwise. The socket is spring loaded and will push the bulb out.
2. Remove the bulb from the socket.
3. Re-insert new bulb by pushing in while turning clockwise.

Additional bulbs may be purchased from your Arrow distributor or a local electrical or electronics supply house. When ordering replacement bulbs, ask for #1820 28-volt miniature bayonet light bulbs.



#1820 28 VOLT MINIATURE BAYONET LIGHT BULB

ALL 4 PANELS
SLIDE TO ALLOW
ACCESS TO
FUSES & BULBS



VII. Troubleshooting


The troubleshooting section will help you, your distributor or a local electrician locate electrical problems that may arise with your bingo system. Several diagrams and schematics have been included in this manual to help you trace any problems. Questions going beyond the information shown here should be directed to your area distributor or directly to Arrow International. Before referring to the table, please check to see that the following conditions are met:

1. Check all connections to system. Look for loose connections or broken wires. Do not attempt to service the control panel in the flashboard or console. Only trained service personnel are qualified to work in this area.
2. If flashboard difficulties arise, check all connections to the flashboard. If power is being supplied to a QD flashboard, the vertical B-O lamps or the highlite lamps for the game number display should be on. If these lamps are not lit, check the primary power to the flashboards.
3. If flashboard primary power is present, run the TEST function at the console (if applicable). When TEST is selected, all lamps on each flashboard will be lit. On the newer Capitol flashboards, a diagnostic self-test is run at power up.
4. Consult troubleshooting table.
5. If further difficulties arise, consult the Arrow factory service center or an authorized distributor.

This troubleshooting table assumes the following conditions:

1. The system is plugged into a 120 volt grounded wall outlet.
2. The power switch is turned on.
3. All balls are in the ball tray.

Troubleshooting Table begins on the next page.



Flashboard Troubleshooting Table —

PROBLEM	CAUSE	CORRECTIVE ACTION
<ul style="list-style-type: none"> No flashboard power 	<ul style="list-style-type: none"> Unit not plugged into outlet No voltage at power outlet Primary fuse defective Power switch off Defective power switch Defective bridge rectifier Defective power transformer 	<ul style="list-style-type: none"> Plug unit into a 120VAC grounded wall outlet. Check outlet with a test lamp or a voltmeter, reset circuit breaker, replace defective fuses, or consult electrician. Replace fuse with a 4Amp Slo Blo ACG/3AG. Turn switch on (up position). Replace switch with a 20 Amp 125VAC UL rated switch. Test bridge rectifier with a voltmeter. There should be a reading of 28VDC between the + & - terminals of bridge rectifier. Replace defective bridge rectifier with (35Amp 800PIV) Arrow part #41940. Test transformer with a voltmeter. 28VAC should be read across the unmarked terminals of the bridge rectifier. If the voltage varies +/- 20%, replace transformer.
<ul style="list-style-type: none"> Primary fuse defective 	<ul style="list-style-type: none"> Defective fuse Defective socket in vertical or horizontal bingo lights Defective bridge rectifier Defective power transformer 	<ul style="list-style-type: none"> Replace fuse with a 4Amp slo blo ACG/3AG style. Disconnect the + lead off bridge rectifier. Replace fuse and carefully turn the power on. If fuse quits opening, examine lamp sockets for shorted sockets or crossed wires. Will read about 22 ohms if good. Replace the defective light sockets. Remove unmarked terminals from bridge. Do not let wires touch. Replace fuse and carefully turn power on. If fuse quits opening, turn the power off and change the bridge rectifier (35Amp 800PIV). Test transformer with a voltmeter. 28 VAC should be read across the unmarked terminals of the bridge rectifier. If the voltage varies +/- 20%, replace transformer-Arrow part #42720.

**Flashboard Troubleshooting Table —
continued**

PROBLEM	CAUSE	CORRECTIVE ACTION
<ul style="list-style-type: none"> • B-O lamps on with no response from console 	<ul style="list-style-type: none"> • Defective data cable • Flashboard printed circuit board configured incorrectly • 1 Amp logic fuse blown • Defective printed circuit board • Using wrong flashboard for particular console 	<ul style="list-style-type: none"> • Repair or replace data cable. Check for loose or dirty connections and frayed or broken wires. • Check W2 jumper setting. Refer to pg. 20 for proper setting for applications. • Replace fuse with a 1Amp slo blo ACG/3AG style on ACRC printed circuit board. Refer to pg. 9 for access details. • Replace ACRC PCB in flashboard. Refer to pg. 9 for access details. • Consult factory.
<ul style="list-style-type: none"> • No response to ball insertion in tray 	<ul style="list-style-type: none"> • Lamp failure • Lamp socket failure • Defective crimp on ribbon cable • SCR/Darlington failure • ACRC PCB failure 	<ul style="list-style-type: none"> • Turn power off and replace lamp in FB (use #1820 for 4" or #1829 for 2" board). refer to pg 9 for access details. • Check connections on back of lamp socket. Use an ohm meter to check for a shorted lamp socket. (0 ohms). Replace defective socket. If good, meter will read about 22 ohms. • Check both ends of ribbon cable, recrimp connection or replace ribbon cable. • Refer to map corresponding to style of PCB (pgs. 20-22) Change SCR/Darlington. SCR's must be desoldered to be replaced. To replace a Darlington, use an IC puller or small screwdriver to gently pry the darlington out of the socket. Use #41947 for darlington. • Replace ACRC PCB. Refer to pg. 9 access.

**Flashboard Troubleshooting Table —
continued**

PROBLEM	CAUSE	CORRECTIVE ACTION
<ul style="list-style-type: none"> Lamp stays illuminated When ball tray is cleared 	<ul style="list-style-type: none"> Defective SCR/Darlington Defective ACRC PCB 	<ul style="list-style-type: none"> Refer to map corresponding to style of PCB (pgs. 20-22). Change SCR/Darlington. SCR's must be desoldered to be replaced. To replace a Darlington, use an IC puller or small screwdriver to gently pry the darlington out of the socket. Use #41947 for darlington. Replace ACRC PCB. Refer to pg. 9 access.
<ul style="list-style-type: none"> Flashboard blinks or lights flicker 	<ul style="list-style-type: none"> Loose data cable Incorrect printed circuit board configuration Defective ACRC PCB 	<ul style="list-style-type: none"> Check both ends of the data cable for loose connections or frayed wires. Replace data cable as necessary. Refer to pg 20 W2 jumper settings for corresponding PCB configuration. Set jumpers on ACRC PCB for specific application. Replace ACRC PCB. Refer to pg. 9 for access.
<ul style="list-style-type: none"> Lights dim 	<ul style="list-style-type: none"> Dirty plexiglass Defective bridge rectifier Low line voltage 	<ul style="list-style-type: none"> Refer to pg. 8 for cleaning instructions. Test bridge rectifier with a volymer. There should be a reading of 28VDC between the + and - terminals of bridge rectifier. Replace defective bridge rectifier with (35AMP 800PIV) Arrow part #41940. Should read above 105VAC. Consult electrician.
<ul style="list-style-type: none"> Group of 30 lights out 	<ul style="list-style-type: none"> Defective secondary fuse 	<ul style="list-style-type: none"> Refer to fuse map on pgs. 18 & 19. Replace with a 3.2 Amp slo blo 3AGC/3AG fuse.

VIII. Electrical Specifications

A. Commander console

120VAC 5AMP MAX (No load on auxiliary power outlets)
120VAC 12AMP MAX(Full load on auxiliary power outlets)
Maximum auxiliary outlet rating: 6AMP, 720WATTS

Blower Fuse

6AMP Normal Blow

B. PC Admiral console

120VAC 7AMP MAX (No load on auxiliary power outlet)
120VAC 12AMP MAX (Full load on auxiliary power outlet)
Maximum auxiliary outlet rating: 6AMP, 720WATTS

Blower Fuse


6AMP Normal Blow

C. 4" Flashboard - Numbers, Game Indicator and Dollar Value


Total power required: 5.25 AMPS or 630W
Primary fuse rating: 4 AMP slo-blo
Secondary fuse rating: 3.2 Amp slo-blo

IX. Wiring Diagrams


A. Commander Wiring Diagram




B. PC Admiral Wiring Diagram




C. Flashboard Data Cables




D. 4" Flashboard Primary Wiring Schematics - Numbers, Game indicator & Dollar Value



E. Bridge Rectifier





F. ACRC Darlington Map



G. ACRC Darlington Map Detail

LAMP NUMBERS	DRIVER (92068B)	LAMP NUMBERS	DRIVER (92068B)
NUMBERS:		DOLLER VALUE:	
B 1-4	U5	10000-B,C,E,G	U80
B 5-8	U4	10000-D,F,A	U81
B 9-12	U2	1000-B,C,E,G	U78
B 13-15	U1	1000-D,F,A	U77
I 16-19	U11	100-B,C,E,G	U86
I 20-23	U10	100-D,F,A	U87
I 24-27	U8	10-B,C,E,G	U84
I 28-30	U7	10-D,F,A	U83
N 31-34	U17	1-B,C,E,G	U32
N 35-38	U16	1-D,F,A	U31
N 39-42	U14		
N 43-45	U13	LAST NO. CALLED:	
G 46-49	U23	10'S-B,C,E,G	U74
G 50-53	U22	10'S-D,F,A	U75
G 54-57	U20	1'S-B,C,E,G	U72
G 58-60	U19	1'S-D,F,A	U71
O 61-64	U29	NUMBER OF BALLS:	
O 65-68	U28	10'S-B,C,E,G	U68
O 69-72	U26	10'S-D,F,A	U69
O 73-75	U25	1'S-B,C,E,G	U66
		1'S-D,F,A	U65
GAME PATTERN:		B-G LETTERS	U35
GP 1-4	U59	O LETTER	U34
GP 5-8	U60		
GP 9-12	U62		
GP 13-16	U63		
GP 17-20	U53		
GP 21-24	U54		
GP 25	U56		
JUMPER 1 & 2 FOR COMMANDER NO JUMPER 1 & 2 FOR PRES. JUMPER 1 & 2 FOR CONT. SELF TEST NO JUMPER 3 & 4 FOR SINGLE SELF TEST		JUMPER 1 & 2 FOR GAME IND. NO JUMPER 1 & 2 FOR DOLLAR VALUE JUMPER 1 & 2 FOR TIME OUT NO JUMPER 3 & 4 FOR CONT. SELF TEST	
REV. 2.0		REV. 2.3	

SEGMENTS MAP #S ONLY



GAME PATTI INDICATO FRONT VIE

Capitol Bingo Equipment Limited Warranty

Set out below are the terms of the Limited Warranty made by Arrow International, Inc. ("Arrow") in connection with the sale of the Capitol Bingo Equipment (the "Equipment").

1. Limited Warranty

Arrow warrants to the original purchaser ("Purchaser") that the Equipment will, for a period of one year from the date of original purchase from an authorized Arrow dealer, be free from manufacturing defects in material and workmanship. Purchaser represents to Arrow that no employee, agent, or representative of Arrow (or of an Arrow dealer) has made any representation or warranty regarding the Equipment except as set out herein.

THE WARRANTY CARD MUST BE COMPLETED AND RETURNED TO ARROW WITHIN 30 DAYS OF PURCHASE FROM AN AUTHORIZED CAPITOL BINGO EQUIPMENT DISTRIBUTOR FOR THIS LIMITED WARRANTY TO BE EFFECTIVE. A purchase receipt or other proof of date of original purchase must be submitted with the Warranty Card and will be required before warranty service is rendered.

This Limited Warranty applies to normal commercial use and does not cover damage which occurs in shipment; failures which are caused by products not supplied by Arrow, failures which result from accident, misuse, abuse, neglect, mishandling, misapplication, alteration, set-up adjustments or modifications. This Limited Warranty does not cover any damage to the Equipment resulting from failure to install in strict conformity with both local fire and building codes and regulations, or if installation does not comply with the installation instructions provided by Arrow.

2. Disclaimer of Warranties

Arrow makes no warranties, express or implied (including, without limitation, merchantability, fitness for particular purpose, or against infringement of any patent), except as expressly provided herein. The express warranties provided herein are in lieu of and exclude all other warranties, guarantees or representations, express or implied, whether arising by operation of law or otherwise.

3. Limitation of Remedies

If the Equipment supplied does not conform to the Limited Warranty set out above, Arrow will, at its option, (a) repair or replace the Equipment, or part thereof, which is defective or (b) refund so much of the purchase price as Purchaser has paid for the defective Equipment, less 1/24th of the purchase price for each month between the date of the purchase from an authorized Arrow dealer and the date of the discovery of the defect, provided that written notice of the defect and its nature is given to Arrow as soon as practical after discovery of the defect, but in no event later than 90 days from the date of the discovery of the defect.

4. Limitation of Liability

The remedy of repair, replacement, or refund of the purchase price is Purchaser's sole and exclusive remedy and will satisfy all of Arrow's liabilities, whether based on contract, negligence, tort, product liability, strict liability, or otherwise. **IN NO EVENT WILL ARROW BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES, NOR WILL ITS INABILITY IN CONNECTION WITH ANY EQUIPMENT OR SERVICE SOLD (INCLUDING NONDELIVERY OR LATE DELIVERY THEREOF) EXCEED THE SALES PRICE OF SUCH EQUIPMENT OR SERVICE.**

5. Warranty Voided

Any obligations of Arrow under this Limited Warranty will be deemed to have been satisfied if anyone other than an authorized Capitol Bingo Equipment Dealer services the Equipment.

6. Transfer of Limited Warranty

Purchaser may transfer its rights under this Limited Warranty, subject to the terms and conditions hereof, to a buyer ("Buyer") from Purchaser of the Equipment. Thereafter, the rights under this Limited Warranty are not transferable. For the transfer by Purchaser of the Limited Warranty to be effective, the following conditions must have occurred no later than the 30th day following the date of resale to Buyer:

- A. Purchaser must have complied with all requirements to make the Limited Warranty effective as to Purchaser;
- B. The Equipment (as an entire unit and as purchased by Purchaser) must be transferred to Buyer; and
- C. Buyer must have submitted a new warranty card together with proof of purchase by Buyer from Purchaser.

Upon an effective transfer of this Limited Warranty, Buyer will be considered to be "Purchaser" for paragraphs 1 and 4 hereof.

7. Inspection

With respect to any claim that the Equipment is defective, Arrow will be allowed a reasonable time to inspect the Equipment, in place. If the Equipment is altered or removed before Arrow has made such inspection or waived its right to do so, the obligations of Arrow will be deemed to have been satisfied.

8. Limitation of Actions

Any legal action against Arrow for a default of its obligations under this Limited Warranty must be commenced within two years from the date the Equipment was sold by an authorized dealer of the Equipment.

9. How to Obtain Service

If a problem with this Equipment develops during or after the warranty period, proceed as follows:

- A. Refer to your Operator's Manual and follow the Troubleshooting Table within the "Service Section."
- B. Contact the authorized Capitol Bingo Equipment Distributor from whom you purchased the Equipment.
- C. Contact the Capitol Bingo Equipment Service Manager at the most convenient phone number listed below:

1 (800) 321-0757 outside Ohio, but within the U.S.A.

1 (800) 537-3479 within the state of Ohio

1 (216) 961-3500 within the 216 area code or
outside the continental U.S.A.

1 (216) 281-5250 FAX

SERVICE CALLS WHICH DO NOT INVOLVE DEFECTIVE MATERIALS OR WORKMANSHIP AS DETERMINED BY ARROW IN ITS SOLE DISCRETION, ARE NOT COVERED. COST OF SUCH SERVICE CALLS ARE THE RESPONSIBILITY OF THE PURCHASER.

Arrow wants you to remain a satisfied customer. If a problem occurs that cannot be resolved to your satisfaction, please contact us immediately. Phone one of the numbers listed above or write to:

Capitol Bingo Equipment Division
c/o National Service Manager
9900 Clinton Rd.
Cleveland, Ohio 44144

Please be sure to include the name, model number, serial number, date of original purchase, and the distributor from whom you purchased the Equipment, as well as any actions taken to correct the problem.

WARNING:
**You must return the
 enclosed warranty card
 immediately in order to
 insure proper warranty
 coverage**

CUSTOMER WARRANTY CARD
CAPITOL BINGO EQUIPMENT OWNER REGISTRATION CARD

Model No. _____
 Serial No. _____
 PCB No(s). _____

Distributor Purchased From _____
 Date Purchased _____
 Name of Organization _____
 Address _____ Phone () _____
 City _____ State _____ Zip _____
 Chairman _____
 Address _____ Phone () _____
 City _____ State _____ Zip _____

Additional Information (Optional) **ATTACH PROOF OF PURCHASE DATE**
 Purchase Price _____ Average Attendance _____
 No. Of Night Games Played _____
 Time Games Played _____ Average Spending Per Person _____

ARROW INTERNATIONAL, INC.

and our subsidiaries

CAPITAL GAME MANUFACTURING

METRO GAME MANUFACTURING

9900 Clinton Rd., Cleveland, Ohio 44144

1 (800) 321-0757 outside Ohio, but within the U.S.A.

1 (800) 537-3479 within the state of Ohio

1 (216) 961-3500 within the 216 area code or outside the continental U.S.A.

1 (216) 281-5250 FAX

© 1992 Capitol Bingo Equipment Division of Arrow International, Inc.

